Vickers®

Directional Controls



Directional Control Valves CETOP 3 Size Soft Shift

DG4V 3 (S) - **(L) 2 ** - (P2) - (V) M - ****(L) - **H * - 60 - (P* - A* - B* - T*)



Model	Knob	*Core Tube S/A	
DG4V-3-2-*	508113	02-300529	
DG4V-3S-2-*	694272	02-135785	
DG4V-3-2-P2-*	508113	02-300529	
DG4V-3S-2-P2-*	694272	02-135785	

Restrictor Plug Install In P,T,A, Or B As Required

CODE	ORIFICE DIA.	PART #		
03	694341			
06				
08	0,80 (0.030)	694343		
10 1,00 (0.040)		694344		
13	1,30 (0.050)	694345		
15	1,50 (0.060)	694346		
20	2,00 (0.080)	694347		
23	2,30 (0.090)	694348		

■ 473710 Screw W/J models (2 Req'd)

■ # 473269 Screw P12L models (2 Req'd)


□471027 Washer P12L models (2 Req'd)

■▲ 262327 "O" Ring P12L models (4 Req'd) "C" models (2 Req'd) "A/B" models

Orifice (1 req'd per core tube) Refer to Orifice Changing Procedure

CODE PART #		COLOR	
00 Orifice omitte			
07	635134	Green	
08	635135	Blue	
09	893320	Purple	

Blank Nameplates (DG4V-3S-60 Standard Valve) Nameplate Model Code DG4V-3S-***-**-M-U-**60 694302 DG4V-3S-**-**-M-F/FPA3/FPA5-**-60 694386 DG4V-3S-***-**-M-FPB-**-60 694363 DG4V-3S-***-**-M-FPBL-**-60 694362 DG4V-3S-C/N**-**-M-P-**-60 694364 DG4V-3S-A/B/F**-**-M-P-**-60 694365 DG4V-3S-AL/BL/FL**-**-M-P-**-60 694366



0

576915 Screw (ground) W/J models

▲ 262342 "O" Ring

Plug in coil "P12L" (see table)

■ 02–113349 Screw (4 Req'd "F" models)

471277 Screw(2 Req'd "U" models)

■ 471274 Screw (4 Req'd "P12L models)

■890333 Cover W/J models ■890332 Gasket W/J models


■36212 Screw (2 Req'd) W/J models

□ Terminal/Conduit box (See table)

■ 890332 Gasket W/J models

♦Body	Type
507334	Flying lead coil
507731	Din 4400 coil
866039	Plug in coil

◆ Body (See table)



U,KU,SP1,SP2 (1 req'd) A & B,

(2 req'd) C models.

▲262392 "O" Ring

Knob (see table)

) ▲■ 262332 "O" Ring-⊲

(4 Req'd)
■ Orfice plug (see table)

■ 472553 Roll pin-

Spool (see table)


458458 Washer

Spring (see table) Omit A models this end


- ▲ Available in seal kit 858996
- Omit for Din models
- * Included in CoreTube S/A
- Available in qty's. of 25 or more only
- ◆ Not available for sale
- ★ Torque 44–62 lbf. ft.(5,0–7,0 N.m)
- **■** Torque 18–25 lbf. in.(2,3–2,8 N.m)
- ⊞ Torque 22–27 lbf. ft.(30–36 N.m)† Torque 21–26 lbf. in.(2.5–3.0 N.m)

Blank Nameplates (DG4V-3-60 High Performance Valve)				
Model Code	Nameplate			
DG4V-3-***-**-M-U-*7-60	694303			
DG4V-3-***-**-M-U-*2/*6-60	694451			
DG4V-3-***-**-M-F/FPA3/FPA5-*7-60	694387			
DG4V-3-***-**-M-FPB-**-60	865929			
DG4V-3-***-**-M-FPBL-**-60	865930			
DG4V-3-C/N**-**-M-P-**-60	865933			
DG4V-3-A/B/F**-**-M-P-**-60	865934			
DG4V-3-AL/BL/FL**-**-M-P-**-60	865935			


♠ For more information on options refer to service drawing I–3886–S.



DG4V-3(S)-*A2 **-(V)M-FW-60 Spring offset to CYL. "A", shift to center. DG4V-3(S)-*B2 **-(V)M-FW-60 Spring centered, Sol. "A" removed. Refer to other end of valve for common part numbers except as noted.



DG4V-3S-*C2 **-(V)M-FW-60 Spring centered, dual solenoid. Refer to other end of valve for common part numbers except as noted.



DG4V-3(S)-*A2 **-*P2-(V)M-FW-60 Manual override in end cover.
Refer to other end of valve for common part numbers except as noted.

NOTE

Right hand assembly shown for all single solenoid valves, for left hand assembly all parts reversed except body (& spool on "B" builds) and electrical connectors (where applicable).

Model Code Coil Identification Letter

Coil	Coil S/A	Coil S/A	Coil S/A	Coil S/A	Coil S/A	Coil S/A	Coil S/A
letter	Voltage DC	"F" models	"U" models	"SP1" models	"SP2" models	"KU" models	"P12L" models
GH	12 VDC	02-123958	02-123938	02-123950	02-123942	02-140393	02-124274
DTH	18 VDC	02-124394	02-124392	02-124719	02-124389	02-148712	02-124511
HH	24 VDC	02-123959	02-123939	02-123951	02-123943		02-124275
DJH	98 VDC	02-123960	02-123940	02-123952	02-123944		02-124238
PH	110 VDC	02-123961	02-123941	02-123953	02-123945		02-124276
SH	220 VDC	02-124260	02-124441				

Type "F" flying lead coils must be powered by DC electrical signal. Type P12L coils must be powered by 110–120, 50–60 Hz AC rectified to DC signal. DIN rectified connectors ("11" or "12" in model code) can be used to convert AC volts to DC voltage to power the valve.

Model Code	Terminal Box "W/J" Flying lead	Conduit Box "P12L" Plug in	Туре
DG4V3(S)-A/B/C-W	890341		Single/double coil
DG4V3(S)-A/B/C-J	890342		
DG4V3(S)-C-P12L		866000	Double coil with rectifier
DG4V3(S)-A/B-P12L		866001	Single coil with rectifier

Rotate conduit box/rectifier/light assembly 180° for models AL, BL, and 8B with solenoid mounted on B port side of body.

Spool/Spring Arrangement DG4V3/DG4V3S Models

Model	Type	DG4V3 Spool	DG4V3 Spring	DG4V3S Spool	DG4V3S Spring
	2*	892913	890195	892913	507889
-*B/C	_3*/31*	927027	507889	927027	507889
- b/O	_6*	892914	507889	892914	694299
	8*	02-303660	927200	893319	507889
	_33*	892915	507889	892915	507889
	0*	02-148720	890195	02-148720	694299
-*A	2A	892916	890195	892916	507889

Assemble type "3" spool in body with narrow center land towards A port. Assemble type "31" spool in body with narrow center land towards B port.

Orifice Changing Procedure WARNING




 Before breaking a circuit connection make certain that power is off and system pressure has

been released. Lower all vertical cylinders, discharge accumulators and block any load whose movement could generate pressure. Plug all removed units and cap all lines to prevent entry of dirt into the system.


- Using a ⁵/₃₂" hex key, remove manual actuator plug and spring from the end of solenoid (Tightening torque 6.2–7.3 N.m 55–65 lbf.in.)
- Insert extraction tool (878495) into solenoid via the manual actuator opening. Rotate tool until aligned and push pin into slot in armature.
- Using ¹/₂" wrench and tool to prevent the armature from rotating, insert ³/₃₂" hex key down the center of tool and remove orifice plug.
- Replace by the same method, tightening orifice snug to ensure bottoming of threads. Smaller orifices increase response times, larger orifices decrease response time.

Orifice & tool kit 02-140211

For fine tuning shift performance, orifice must be ordered separately. The kit includes (2) each of .7, .8 & .9 mm dia. orifices, (1) installation tool, (1) $^{5}/_{32}$ " hex key and (1) $^{3}/_{32}$ " hex key.



Model Code



■ Valve Type

D – Directional control valve **G** – Subplate mounted Soleniod operated 4 –

٧ Rated pressure 350 bar (5075 psi)

2 Interface

ISO 4401-03, CETOP 3 (NFPA DO3)

3 Valve performance

Standard performance Blank - High performance

4 Spool types

0 -Open center

Closed center (all ports) 2 –

P & B closed, A to T 3 -

6 -Closed center (P only)

Tandem center (open crossover) 8 _

31 _ P & A closed, B to T

33 -Closed center (bleed A & B)

5 Spool/Spring Arrangment

A -Spring offset, single soleniod Same as A but left hand build AL –

B – Spring centered, single solenoid

BL-Same as B but left hand build

C -Spring centered

6 Soft shift valve

7 Soft shift orifice size

00 -No orifice

07 -0.7 mm dia.

08 -0.8 mm dia

09 -0.9 mm dia.

20 -2.0 mm dia*

8 Manual overide options

Blank - Overide in soleniod end only. Manual overide in end cap & solenoid, A & B models only.

9 Reverse solenoid identification

Blank - ANSI B93 energize solenoid A to give flow P to A.

V – Solenoid identification determined by position of soleniod (i.e. solenoid A is at port A end of solenoid B is at port B end of valve).

10 Flag Symbol

(Introduces electrical features М and options.)

F-Flying lead type coils

U-DIN 4400 coils.

SP1 -Single $^{1}/_{4}$ " male spade. Dual $^{1}/_{4}$ " male spade.

SP2 -

P12L - Plug-in coils W/rectifier in junction box, lights included.

KU -Top exit flying leads.

12 Coil Connector Options

("U" type coils only, omit if not required.)

1 – Connector fitted.

Connector with light fitted. 6 –

11 -Rectifier with lights fitted.

12 -Rectifier fitted.

13 ▲ Electrical Connector Options

("F" type coils only, omit if not required.)

PA -Instra-plug male recpt. only.

PA3 -3-pin receptacle.

PA5 -5-pin receptacle.

PB-Insta-plug male & female recpt.

T -Terminal block.

♠ For more information on options refer to service drawing I-3886-S.

14 ♠ Wiring Housing Thread Options

("F" type coils only, omit if not required.)

1/2 " NPT w –

J – M20 x 1.5 - 6H

G -G 1/2 "

Solenoid Indicator Light Options Solenoid Indicator Light Options

(Not available on PA, U, SP1, SP2, omit if not required.)

16 ♠ Coil Identification Letter Options

GH - 12V DC

DTH - 18V DC

HH -24V DC

DJH – 98V DC (reg'd. for P12L models.

PH -110V DC

SH-220V DC

17 Tank Pressure Rating

2 – 10 bar (145 psi) for

5 -100 bar (1450 psi) for DG4V-3S

7 – 207 bar (3000 psi) for DG4V-3

18 Design Number

19 Port Orfices

03 -0.3 mm dia.

06 -0.6 mm dia.

-800.8 mm dia.

10 -1.0 mm dia.

13 -1.3 mm dia. 1.5 mm dia 15 –

2.0 mm dia. 20 -

23 -2.3 mm dia.

(Example: "P03" = 0.3 mm dia, orifice in P port of valve. Omit if not required.)

^{*} Minimun orfice size recommended for high performance type "8C" spool.